

To return to perce.biz, use your browser's 'Back' button. You may print these instructions for future reference.



PerCE Video iPod Instructions

These instructions assume that you have followed Step 8 in the PerCE System Instructions to synchronize a downloaded PerCE course from iTunes to your iPod. If you have not yet done so, plug your iPod into the USB port of your computer to download any PerCE lessons to your iPod before beginning.

To watch a synchronized course from the PerCE System:

1. If the iPod is off, turn it on. To turn the iPod on, first slide the HOLD switch on the top of the unit to the left. This will change the indicator from orange to white.
 - a. If the unit does not automatically turn on, press the Center button.
2. Using the touch-sensitive scroll wheel, highlight "Videos" by scrolling down clockwise with your thumb.
3. Press the Center button.
4. By using the touch-sensitive scroll wheel, highlight "Video Podcasts" and press the Center button.
5. "PerCE Podcast – XXXX" (where "XXXX" is the name of the course) will be highlighted.
6. Press the Center button twice to start the video.
7. You can skip to the next slide by quickly pressing the Fast Forward (▶▶) button and can return to the previous slide by quickly pressing the Rewind (◀◀) one time per slide.
8. When you are through watching the video, return to the main iPod menu by pressing the Menu repeatedly until you see "iPod" on the title bar of the screen.
9. Turn the iPod off by following the directions below in the Common Functions section below.

Common Functions:

- To turn the iPod off, press and hold the Play/Pause (▶ ||) Button until the screen shuts off.
 - To prevent the iPod from accidentally being turned on while not in use, slide the HOLD switch on the top of the unit to the right while the unit is off.
- To control the volume while playing a video, use the touch-sensitive scroll wheel. Scroll clockwise to turn the volume up, counterclockwise to turn the volume down.
- The videos will resume playing where you left off last time you viewed them.
 - To rewind while watching a video, hold down the Rewind (◀◀) button.
 - To fast forward while watching a video, hold down the Fast Forward (▶▶) button.
- To Pause the video, press the "Play/Pause" (▶ ||) button.
- To return to the menu during movie playback, press the Menu button. Each press of the button will take you back one menu level.
- To charge the iPod, use the included USB to iPod connector cable to plug the iPod into any USB port on a computer. You will see a blinking battery icon while the iPod is charging. When fully charged, the battery icon is solid green.